



<b>RALT 2320 SET</b>			
<b>Pozice</b>	<b>Obj.číslo</b>	<b>Popis</b>	<b>Počet ks</b>
1	RALT2320-1	wheel shaft gasket	2
2	RALT2320-2	big wheel shaft	2
3	RALT2320-3	big trimming wheel	1
4	RALT2320-4	protect steel	1
5	RALT2320-5	Screw	1
6	RALT2320-6	square nuts	1
7	RALT2320-7	small wheel shaft	1
8	RALT2320-8	small trimming wheel	1
9	RALT2320-9	pan head self tapping screw	25
10	RALT2320-10	right housing	1
11	RALT2320-11	right housing decoration cover	1
12	RALT2320-12	shock pad	2
13	RALT2320-13	limit button	1
14	RALT2320-14	Rotated head lock button spring	1
15	RALT2320-15	right housing rotate head	1
16	RALT2320-16	Tube cap	1
17	RALT2320-17	pan head self tapping screw	8
18	RALT2320-18	tube inner	1
19	RALT2320-19	lower tube	1
20	RALT2320-20	Anti scrach sleeve	1
21	RALT2320-21	Telescopic sleeve 2	1
22	RALT2320-22	Telescopic sleeve	1
23	RALT2320-23	Auxiliary handle	1
24	RALT2320-24	Lock knob	1
25	RALT2320-25	hex nuts	1
26	RALT2320-26	Right decoration cover	1
27	RALT2320-27	Lock button	1
28	RALT2320-28	Lock button spring	1
29	RALT2320-29	Right handle	1
30	RALT2320-30	Switch	1
31	RALT2320-31	Sleeve	1
32	RALT2320-32	Trigger	1
33	RALT2320-33	switch trigger	1
34	RALT2320-34	press plate	2
35	RALT2320-35	left handle	1
36	RALT2320-36	battery pack assembly	1
37	RALT2320-37	battery pack right connector base	1
38	RALT2320-38	Diode	1
39	RALT2320-39	battery pack left connector base	1
40	RALT2320-40	left handle decoration cover	1
41	RALT2320-41	screw	1
42	RALT2320-42	pole holder	1
43	RALT2320-43	Pole	2
44	RALT2320-44	upper tube	1
45	RALT2320-45	Spring cable	1
46	RALT2320-46	Lock sleeve	1
47	RALT2320-47	Plastic button	2

48	RALT2320-48	left housing rotate head	1
49	RALT2320-49	left housing	1
50	RALT2320-50	left housing decoration cover	1
51	RALT2320-51	Protect cover	1
52	RALT2320-52	Spring	1
53	RALT2320-53	String roller	1
54	RALT2320-54	String	1
55	RALT2320-55	String eyelet	2
56	RALT2320-56	String case cover	1
57	RALT2320-57	Blade	1
58	RALT2320-58	Screw	1
59	RALT2320-59	Circlip	1
60	RALT2320-60	motor	1
61	RALT2320-61	motor cover	1
62	RALT2320-62	Screw	2
63	RALT2320-63	String case	1
64	RALT2320-64	motor shaft sleeve	1
65	RALT2320-65	Nylon blade	10
66	RALT2320-66	Rivert	2
67	RALT2320-67	Nylon blade seat	1
68	RALT2320-68	Gasket	2
901	RALT2320-901	Nylon blade seat assembly	1
902	RALT2320-902	Motor assembly	1
903	RALT2320-903	String trimmer assembly	1
904	RALT2320-904	String assembly	1